

Installation and service instructions

for contractors

VIESSMANN

Vitodens 100-W

Type B1HC, B1KC, 4.7 to 35.0 kW

Wall mounted gas condensing boiler

Natural gas and LPG version

Gas Council Number: 41-819-40, 41-819-41, 41-819-42, 41-819-43, 47-819-40,
47-819-41, 47-819-42,

For applicability, see the last page



VITODENS 100-W



Safety instructions



Please follow these safety instructions closely to prevent accidents and material losses.

Safety instructions explained



Danger

This symbol warns against the risk of injury.



Please note

This symbol warns against the risk of material losses and environmental pollution.

Note

Details identified by the word "Note" contain additional information.

Target group

These instructions are exclusively intended for qualified contractors.

- Work on gas installations must only be carried out by a registered gas fitter.
- Work on electrical equipment must only be carried out by a qualified electrician.
- The system must be commissioned by the system installer or a qualified person authorised by the installer.

Regulations to be observed

- National installation regulations
- Statutory regulations for the prevention of accidents
- Statutory regulations for environmental protection
- Codes of practice of the relevant trade associations
- All current safety regulations as defined by DIN, EN, DVGW, TRGI, TRF, VDE and all locally applicable standards
 - Ⓐ ÖNORM, EN, ÖVGW-TR Gas, ÖVGW-TRF and ÖVE
 - ⓐ SEV, SUVA, SVGW, SVTI, SWKI, VKF and EKAS guideline 1942: LPG, part 2

Safety instructions for working on the system

Working on the system

- Where gas is used as the fuel, close the main gas shut-off valve and safeguard it against unintentional reopening.
- Isolate the system from the power supply, e.g. by removing the separate fuse or by means of a mains isolator, and check that it is no longer 'live'.
- Safeguard the system against reconnection.



Danger

Hot surfaces can cause burns.

- Before maintenance and service work, switch OFF the appliance and let it cool down.
- Never touch hot surfaces on the boiler, burner, flue system or pipework.



Please note

Electronic assemblies can be damaged by electrostatic discharge.

Prior to commencing work, touch earthed objects such as heating or water pipes to discharge static loads.

Repair work



Please note

Repairing components that fulfil a safety function can compromise the safe operation of the system.

Replace faulty components only with genuine Viessmann spare parts.

Auxiliary components, spare and wearing parts



Please note

Spare and wearing parts that have not been tested together with the system can compromise its function. Installing non-authorised components and making non-approved modifications or conversions can compromise safety and may invalidate our warranty.

For replacements, use only original spare parts supplied or approved by Viessmann.

Safety instructions for operating the system

If you smell gas



Danger

Escaping gas can lead to explosions which may result in serious injury.

- Do not smoke. Prevent naked flames and sparks. Never switch lights or electrical appliances on or off.
- Close the gas shut-off valve.
- Open windows and doors.
- Evacuate any people from the danger zone.
- Notify your gas or electricity supply utility from outside the building.
- Have the power supply to the building shut off from a safe place (outside the building).

If you smell flue gas



Danger

Flue gas can lead to life threatening poisoning.

- Shut down the heating system.
- Ventilate the installation site.
- Close doors to living spaces to prevent flue gases from spreading.

Safety instructions (cont.)**What to do if water escapes from the appliance****Danger**

When water escapes from the appliance there is a risk of electrocution.

Switch off the heating system at the external isolator (e.g. fuse box, domestic power distribution).

Flue systems and combustion air

Ensure that flue systems are clear and cannot be sealed, for instance due to accumulation of condensate or other causes. Ensure an adequate supply of combustion air.

Instruct system users that subsequent modifications to the building characteristics are not permissible (e.g. cable/pipework routing, cladding or partitions).

**Danger**

Leaking or blocked flue systems, or an inadequate supply of combustion air can cause life threatening poisoning from carbon monoxide in the flue gas.

Ensure the flue system is in good working order. Vents for supplying combustion air must be non-closable.

Extractors

Operating appliances that extract air to the outside (cooker hoods, extractors, air conditioning units, etc.) can create negative pressure. If the boiler is operated at the same time, this can lead to reverse flow of the flue gas.

**Danger**

The simultaneous operation of the boiler and appliances that extract air to the outside can result in life threatening poisoning due to reverse flow of the flue gas.

Fit an interlock circuit or take suitable steps to ensure an adequate supply of combustion air.

1. Information	Disposal of packaging	6
	Symbols	6
	Intended use	6
	Product information	7
	■ Vitodens 100-W, type B1HC, B1KC	7
	Product description	7
	■ DHW heating with DHW cylinder	7
	■ Connecting accessories	7
2. Preparing for installation	8
3. Installation sequence	Mounting the boiler and making the connections	11
	■ Hooking the boiler onto the wall mounting bracket	11
	■ Fitting the connections on the water side	11
	■ Gas connection	13
	■ Connecting the safety valve and condensate drain	13
	■ Filling the trap with water	14
	■ Balanced flue connection	14
	Removing the front panel	15
	Opening the control unit enclosure	15
	Electrical connections	16
	■ Cable routing	18
	■ Outside temperature sensor (accessories)	18
	■ Vitotrol 100 connection	18
	■ Power supply	19
	■ Routing cables/leads and closing the control unit enclosure	19
4. Commissioning, inspection, maintenance	Steps - commissioning, inspection and maintenance	20
5. Gas type conversion	Converting from operation with LPG to operation with natural gas	45
	■ Checking the CO ₂ content	45
6. Troubleshooting	Function sequence and possible faults	46
	Fault display	46
	Repairs	49
	■ Removing the front panel	49
	■ Outside temperature sensor	50
	■ Boiler water temperature sensor	51
	■ Checking the cylinder temperature sensor (gas condensing boiler) ...	52
	■ Checking the temperature limiter	53
	■ Checking the outlet temperature sensor (gas condensing combi boiler)	53
	■ Checking the flue gas temperature sensor	54
	■ Replacing the flow limiter (gas condensing combi boiler)	55
	■ Checking or replacing the plate heat exchanger (gas condensing combi boiler)	56
	■ Checking the fuse	57
7. Parts lists	Overview of assemblies	59
	Casing assembly	60
	Heat cell assembly	62
	Burner assembly	64
	Hydraulic assembly	66
	Hydraulic assembly, system boiler	68
	Hydraulic assembly, combi boiler	70
	Control unit assembly	72
	Miscellaneous	74

Index (cont.)

8. Control unit	Functions and operating conditions in weather-compensated mode	76
	■ Heating curve for weather-compensated control	76
	■ Frost protection function	76
9. Connection and wiring diagram	77
10. Reports	78
11. Specification	79
12. Disposal	Final decommissioning and disposal	81
13. Certificates	Declaration of conformity	82
	■ Declaration of Conformity for the Vitodens 100-W	82
14. Keyword index	83

Disposal of packaging










Please dispose of packaging waste in line with statutory regulations.

DE: Use the disposal system organised by Viessmann.







AT: Use the ARA statutory disposal system (Altstoff Recycling Austria AG, licence number 5766).

CH: Packaging waste is disposed of by the HVAC contractor.

Symbols

Symbol	Meaning
	Reference to other document containing further information
	Step in a diagram: The numbers correspond to the order in which the steps are carried out.
	Warning of material losses and environmental pollution
	Live electrical area
	Pay particular attention.
	<ul style="list-style-type: none"> Component must audibly click into place. or Acoustic signal
	<ul style="list-style-type: none"> Fit new component. or In conjunction with a tool: Clean the surface.
	Dispose of component correctly.
	Dispose of component at a suitable collection point. Do not dispose of component in domestic waste.

The steps in connection with commissioning, inspection and maintenance are found in the "Commissioning, inspection and maintenance" section and identified as follows:

Symbol	Meaning
	Steps required during commissioning
	Not required during commissioning
	Steps required during inspection
	Not required during inspection
	Steps required during maintenance
	Not required during maintenance

Intended use

The appliance is intended solely for installation and operation in sealed unvented heating systems that comply with EN 12828, with due attention paid to the associated installation, service and operating instructions. It is only designed for heating up heating water that is of potable water quality.

Intended use presupposes that a fixed installation in conjunction with permissible, system-specific components has been carried out.

Intended use (cont.)

Commercial or industrial usage for a purpose other than heating the building or DHW shall be deemed inappropriate.

Any usage beyond this must be approved by the manufacturer in each individual case.

Incorrect usage or operation of the appliance (e.g. the appliance being opened by the system user) is prohibited and will result in an exclusion of liability. Incorrect usage also occurs if the components in the heating system are modified from their intended use (e.g. if the flue gas and ventilation air paths are sealed).

Product information

Vitodens 100-W, type B1HC, B1KC

Preset for operation with natural gas

The Vitodens 100-W may only be delivered to the countries specified on the type plate. For deliveries to other countries, approved contractors must arrange individual approval on their own initiative and in accordance with the law of the country in question. The type plate is located on the top of the boiler (see page 59).

Product description

The Vitodens 100-W is available as a gas condensing boiler for the connection of one DHW cylinder and as a gas condensing combi boiler with an integral plate heat exchanger for DHW heating. For the connection of heating circuits and the DHW cylinder or the DHW line, see from page 11.

In the delivered condition, the Vitodens 100-W is set up for operation with constant boiler water temperature. By connecting an outside temperature sensor (accessories), the boiler can be operated in weather-compensated mode.

The following are integrated: one sealed unvented hydraulic system with 2 connections for heating flow and return, and 2 connections for cylinder heating (gas condensing boiler) or DHW heating (gas condensing combi boiler).

These boilers are only intended for installation in sealed unvented heating systems. Boilers for open vented heating systems are also available. If the Vitodens 100-W is installed in an S plan or Y plan system, the DHW primary connections are not used and must be capped off.

The following components are integrated into the hydraulic system:

- Circulation pump
- 3-way diverter valve
- Safety valve
- Diaphragm expansion vessel
- Plate heat exchanger for DHW heating (gas condensing combi boiler)

DHW heating with DHW cylinder

If a Viessmann Vitocell is connected, a cylinder temperature sensor will issue the heat demand (accessories). The cylinder temperature sensor is connected to the boiler control unit. A 230 V cylinder temperature controller is not required.

If a different DHW cylinder is connected, the cylinder temperature sensor (accessories) may also be used on this cylinder. Alternatively, a 230 V cylinder temperature controller should be connected via the cylinder demand junction box (part of the boiler standard delivery).

Connecting accessories

Cylinder temperature sensor, outside temperature sensor and time switch are connected to the control unit with low voltage.

Preparing for installation

Preparing for boiler installation

Dimensions and connections




Fig. 1

- Ⓐ Heating flow Ø 22 mm
- Ⓑ Gas condensing boiler:
Cylinder flow G $\frac{3}{4}$
Gas condensing combi boiler:
DHW Ø 15 mm
- Ⓒ Gas connection
- Ⓓ Gas condensing boiler:
Cylinder return G $\frac{3}{4}$
Gas condensing combi boiler:
Cold water Ø 15 mm
- Ⓔ Heating return Ø 22 mm
- Ⓕ Condensate drain/drain safety valve: Plastic hose
Ø 22 mm

Note

Dimensions of connections in conjunction with the connection accessories provided.

Preparing for installation (cont.)

Fitting the wall mounting bracket

Only for installation without installation aid or mounting frame.




Fig. 2

(A) Vitodens installation template

Fitting installation aid or mounting frame (accessories)



Installation aid or mounting frame installation instructions

Preparing the connections



Please note

To prevent appliance damage, connect all pipework free of load and torque stress.

1. Position the supplied installation template on the wall.
2. Mark out the rawl plug holes.
3. Drill \varnothing 10 mm holes and insert the rawl plugs supplied.

Note

The supplied rawl plugs are suitable for the following materials:

- Concrete
- Vertically perforated bricks
- Hollow breeze concrete blocks
- Brick and concrete hollow ceilings
- Perforated sand lime bricks
- Solid sand lime bricks
- Natural stone with dense structure
- Porous concrete
- Solid gypsum panels
- Solid breeze concrete blocks
- Solid bricks

4. Fit wall mounting bracket with screws supplied.

Note

This boiler (IP rating: IP X4) is approved for installation in wet rooms inside safety zone 1 in accordance with IEEE Wiring Regulations, providing the occurrence of hosed water can be ruled out.

Observe the IEEE Wiring Regulations.

1. Prepare the water connections. Flush the heating system.
2. Prepare the gas connection.

Preparing for installation (cont.)

3. Prepare the electrical connections.

- Power cable:
A flexible cable 3 x 1.5 mm², approx. 1.5 m long is connected in the delivered condition.
- Accessory cables:
2-core sheathed cable min. 0.5 mm² for low voltage

Mounting the boiler and making the connections

Hooking the boiler onto the wall mounting bracket




Fig. 3

Fitting the connections on the water side



For installation of fittings on the heating water side and DHW side, see separate installation instructions.




Fig. 4

- | | |
|--|---|
| <p>(A) Heating flow</p> <p>(B) Gas condensing boiler:
Cylinder flow
Gas condensing combi boiler:
DHW</p> <p>(C) Gas connection</p> | <p>(D) Gas condensing boiler:
Cylinder return
Gas condensing combi boiler:
Cold water</p> <p>(E) Heating return</p> |
|--|---|

Mounting the boiler and making the connections (cont.)

Gas condensing boiler

Permiss. DHW operating pressure: 10 bar (1.0 MPa)

Note

Install a pressure reducer if required.




Fig. 5

Gas condensing combi boiler




Fig. 6

Ⓕ Filling device

Mounting the boiler and making the connections (cont.)

Gas connection




Fig. 7

1. Connect the gas shut-off valve to connection (A).
2. Check gas connections for tightness.

Note

Only use suitable and approved leak detection agents (EN 14291) and devices for the tightness test. Leak detection agents with unsuitable constituents (e.g. nitrides, sulphides) can cause material damage.

Remove leak detection agent residues after testing.



Please note

Excessive test pressure will damage the boiler and the gas train.

Max. test pressure 150 mbar (15 kPa). If a higher pressure is required for tightness tests, disconnect the boiler and the gas train from the main supply pipe (undo the fitting).

3. Purge the gas line.

Connecting the safety valve and condensate drain




Fig. 8

- The condensate pipe is connected to the discharge pipe of the safety valve. The supplied condensate hose meets the temperature requirements for CE certification.
- We recommend connecting the condensate pipe to the internal domestic waste water system, either directly or via a tundish.
- If the condensate pipe is routed outside the building, use a pipe with at least 30 mm Ø and protect the pipe from frost. Avoid long external pipe runs.



Please note

A frozen condensate pipe can result in faults and damage to the boiler.

Always protect condensate pipes against frost.

- Observe local building regulations. Connect condensate pipe (A) to the public sewage system with a constant fall and a pipe vent. Observe local waste water regulations.

Note

Fill the trap with water before commissioning.

Mounting the boiler and making the connections (cont.)

Filling the trap with water




Fig. 9

Pour at least 0.3 l of water into the flue outlet.



Please note

During commissioning, flue gas may escape from the condensate drain.
Always fill the trap with water before commissioning.

Balanced flue connection

Note

Only use the "System certificate" and "Skoberne GmbH flue system" labels in conjunction with the Viessmann flue system made by Skoberne.




Fig. 10

Connect the balanced flue pipe.
During installation and positioning of the flue system, observe Part L and BS 5440 building regulations.



Flue system installation instructions

Connecting several Vitodens 100-W to a shared flue system

Adjust the burner setting of each connected boiler to match the flue system:

- For shared connection, see page 27.
- For flue gas cascade, see page 32.

Do not carry out **commissioning** until the following conditions are met:

- Free passage through the flue gas pipes.
- Flue system with positive pressure is gas-tight.
- Apertures for ensuring sufficient combustion air supply are open and cannot be closed off.
- Applicable regulations on installing and commissioning flue systems have been followed.



Danger

Leaking or blocked flue systems or an insufficient supply of combustion air cause life threatening poisoning due to carbon monoxide in the flue gas.

Ensure the flue system functions correctly. Apertures for combustion air supply must not be able to be closed off.

Removing the front panel




Fig. 11

1. Undo the screws at the bottom of the boiler; do not remove completely.
2. Remove the front panel.

Opening the control unit enclosure




Fig. 12

Opening the control unit enclosure (cont.)

- ! Please note**
Electronic assemblies can be damaged by electrostatic discharge.
Prior to commencing any work, touch earthed objects such as heating or water pipes to discharge static loads.

Electrical connections



Information on connecting accessories

When connecting accessories observe the separate installation instructions provided with them.




Fig. 13

- (A) Only for weather-compensated mode:
Outside temperature sensor (accessories)
- (B) OpenTherm device
Remove jumper (D) when making this connection.
- (C) Connecting cable
- (D) Jumper
- (E) Power supply (230 V, 50 Hz).
See page 19.
- (F) Vitotrol 100 or on-site room temperature controller
(230 V switched input)
Remove jumper (D) when making this connection.
 Separate installation instructions
- [5] Gas condensing boiler:
 - For Viessmann DHW cylinders: Cylinder temperature sensor (plug on the cable harness outside the control unit)
 - In the case of alternative DHW cylinders compliant with the G3 Directive:
Cylinder demand junction box (for connection of a cylinder temperature controller and a 2-way shut-off valve)
 - Operation without DHW cylinder:
Set the set DHW temperature to "OFF".
 Operating instructions

Electrical connections (cont.)

Connection of room temperature controller with time switch and DHW cylinder with 2-way valve and 230 V cylinder temperature controller




Fig. 14

- | | |
|--|-------------------------------|
| Ⓐ Terminal box cylinder demand (accessories) | Ⓔ 2-way shut-off valve |
| Ⓑ Jumper, remove when making this connection | Ⓕ High limit safety cut-out |
| Ⓒ Power supply (230 V, 50 Hz).
See page. | Ⓖ Time switch |
| Ⓓ 230 V cylinder temperature controller | Ⓗ Room temperature controller |

Cable routing




Fig. 15

- (A) Power cable, remote control connecting cable
- (B) LV leads (sensor leads)

Outside temperature sensor (accessories)

1. Fit outside temperature sensor.

Installation location:

- North or north-westerly wall, 2 to 2.5 m above ground level; in multi storey buildings, in the upper half of the second floor
- Not above windows, doors or vents
- Not immediately below balconies or gutters
- Never render over
- Connection:
2-core lead, length up to 35 m with a cross-section of 1.5 mm²

2. Connect the outside temperature sensor to terminals 3 and 4 of the power cable at slot "X21" (see page 16).

Vitotrol 100 connection




Fig. 16 Example: Vitotrol 100, type UTDB

- (A) Vitotrol 100, type UTDB
- (B) Terminals "X1/96" on the control unit
- (C) Jumper, remove when making this connection

Recommended connecting cable

- 2-core cable with a cross-section of 1.5 mm² for 230 V~

Electrical connections (cont.)

Power supply

Regulations and Directives




Danger

Incorrectly executed electrical installations can result in injuries from electrical current and in damage to the appliance.

Connect the power supply and implement all safety measures (e.g. RCD circuit) in accordance with the following regulations:

- VDE regulations
- Connection requirements specified by your local power supply utility

Install an isolator in the power cable to provide omnipolar separation from the mains for all active conductors, corresponding to overvoltage category III (3 mm) for full isolation. This isolator must be fitted in the permanent electrical installation, in line with the installation requirements.

We also recommend installing an AC/DC-sensitive RCD (RCD class B ) for DC (fault) currents that can occur with energy efficient equipment. Protect the power cable with a fuse/MCB of up to 16 A.



Danger

Incorrect core assignment can result in serious injury and damage to the appliance. Take care **not** to interchange wires "L1" and "N".



Danger

The absence of component earthing can lead to serious injury from electric current if an electrical fault occurs.

The appliance and pipework must be connected to the equipotential bonding of the building.

Routing cables/leads and closing the control unit enclosure



Please note

Connecting cables/leads will be damaged if they touch hot components.

When routing and securing cables/leads on site, ensure that the maximum permissible temperature for these is not exceeded.




Fig. 17



Steps - commissioning, inspection and maintenance

	Commissioning steps	Inspection steps	Maintenance steps		Page
•	•	•	•	1. Filling the heating system.....	21
•	•	•	•	2. Venting the boiler by flushing.....	22
•	•	•	•	3. Converting the gas type	23
•	•	•	•	4. Checking the static pressure and supply pressure.....	24
•				5. Reducing the maximum heating output.....	25
•				6. Matching the circulation pump rate to the heating system.....	25
•				7. Matching the burner output to the flue system.....	26
•				8. Burner adjustment when connecting multiple flues to a shared flue system.....	26
•				9. Adjust the burner setting if several boilers are connected to a shared flue (flue gas cascade).....	32
•				10. Checking the CO ₂ content.....	35
	•	•		11. Removing the burner	37
	•	•		12. Checking the burner gasket and burner gauze assembly.....	37
	•	•		13. Checking and adjusting the electrode.....	38
	•	•		14. Cleaning the heat exchanger.....	39
	•	•		15. Checking the condensate drain and cleaning the trap.....	40
	•	•		16. Installing the burner	40
	•	•		17. Checking the diaphragm expansion vessel and system pressure.....	41
•	•	•		18. Checking all connections on the heating water side and DHW side for leaks	
•	•	•		19. Checking the flue system for unrestricted flow and tightness	
•	•	•		20. Checking the firm seating of electrical connections	
•	•	•		21. Checking all gas equipment for tightness at operating pressure	42
	•	•		22. Mounting the front panel.....	42
•				23. Setting the DHW comfort function.....	42
•				24. Setting display backlight for standby.....	43
•				25. Setting display contrast.....	43
•				26. Setting the signal tone for display operation.....	43
•				27. Instructing the system user.....	44



Filling the heating system




Please note

Unsuitable fill water increases the level of deposits and corrosion and may lead to boiler damage.

- Flush the heating system thoroughly before filling.
- Only fill with water of potable quality.
- Fill water with a hardness above 300 ppm must be softened.
- Special antifreeze suitable for heating systems can be added to the fill water.

1. Close the gas shut-off valve.
2. Switch ON the power supply.
3. Tap **MODE**.
4. ▲/▼ until **CONF** flashes.
5. **OK** to confirm.
"P" appears in the l.h. display area. The r.h. display area flashes.
6. Use ▲/▼ to select "12".
7. **OK** to confirm.
"1" flashes in the l.h. display area.
8. **OK** to confirm.
"0" flashes in the r.h. display area.
9. Use ▲/▼ to select "1".
10. **OK** to confirm.
Filling is activated. The boiler circuit pump is running, the 3-way diverter valve moves to its centre position. This function terminates automatically after 30 min or when the ON/OFF switch is switched off.

Gas condensing boiler



1. Open shut-off valves (A) and (if fitted) (B).
2. Connect fill hose to valve (C) and open valve (C).
3. Fill the heating system. [A removable filling loop with double check valve must be used in UK] (system pressure 0.8 to 1.2 bar).
4. Close valve (C).

Fig. 18



Gas condensing combi boiler




Fig. 19

1. Open shut-off valves (A) and (if fitted) (B).

2. Open valves (C) and (D).

Note

The cold water supply must be open.

3. Fill the heating system [a removable filling loop with double check valve must be used in UK] (system pressure 0.8 to 1.2 bar).

4. Close valves (C) and (D).

5. Remove the connection line between valves (C) and (D). During operation, the connection **must** be interrupted.



Venting the boiler by flushing

Note

Inadequate ventilation can result in damage due to steam blasts in the heat exchanger.



Venting the boiler by flushing (cont.)




Fig. 20

1. Connect the drain hose on shut-off valve (A) to a drain.
2. Close shut-off valve (B).
3. Open valves (A) and (C) and flush at mains pressure until no more sounds of escaping air can be heard.
4. First close valve (A) and then valve (C).
5. Adjust the operating pressure ≥ 0.8 bar (80 kPa) with valve (C).
6. Open shut-off valve (B).
7. Disconnect drain hose and keep safe.



Converting the gas type

In the delivered condition, the boiler is set up for operation with natural gas (G 20).
For operation with a different gas type, install a conversion kit and change over the gas type at the control unit.

Enter the selected gas type and the associated limits for flue gas emissions in the table below.



For values, see separate installation instructions.



Separate installation instructions

Selected gas type

	Gas type	Date	CO ₂ content in %	O ₂ content in %	CO content in ppm
Delivered condition	G 20		7.5 - 10.5		< 1000
Changed to					< 1000
Changed to					< 1000



Checking the static pressure and supply pressure



Danger

CO formation as a result of incorrect burner adjustment can have serious health implications. Check the CO content before and after carrying out work on gas appliances.

Operation with LPG

Purge the LPG tank twice when commissioning or making a replacement. Vent the tank and gas connection line thoroughly after purging.




Fig. 21

1. Close the gas shut-off valve.
2. Undo screw (A) inside test connector "IN" on the gas train but do not remove it, and connect the pressure gauge.
3. Open the gas shut-off valve.
4. Check the static pressure.

Set value:

- Natural gas: 20 mbar (2.0 kPa)
- LPG: 37 mbar (3.7 kPa)

5. Start the boiler.

Note

During commissioning, the boiler can enter a fault state because of airlocks in the gas line. After approx. 5 s, tap "R" for approx. 2 s to reset the burner.

Ensure that enough heat is being drawn during the testing and setting processes.

6. Check the supply (flow) pressure.
Set value: See type plate.

Note

Use a suitable tester with a resolution of at least 0.1 mbar (10 Pa) to check the supply pressure.

7. Implement measures as indicated in the table below.
8. Shut down the boiler, close the gas shut-off valve, remove the pressure gauge and close test connector (A) with the screw.
9. Open the gas shut-off valve and start the appliance.



Danger

Gas escaping from the test connector leads to a risk of explosion.
Check gas tightness at test connector (A).

Note

The maximum pressure drop between the gas shut-off valve and test connector (A) at the gas train is 0.5 mbar (50 Pa).

Supply pressure (flow pressure)		Measures
For natural gas	For LPG	
below 10 mbar (1.0 kPa)	below 25 mbar (2.5 kPa)	Do not start the boiler. Notify your gas supply utility or LPG supplier.
10 to 33 mbar (1.0 to 3.3 kPa)	25 to 57.5 mbar (2.5 to 5.75 kPa)	Start the boiler.
above 33 mbar (3.3 kPa)	above 57.5 mbar (5.75 kPa)	Install a separate gas pressure governor upstream of the system and set it to the nominal pressure (see type plate). Notify your gas supply utility or LPG supplier.



Reducing the maximum heating output

The maximum heating output can be reduced according to the system requirements.

1. Tap **MODE**.
2. ▲/▼ until **CONF** flashes.
3. **OK** to confirm.
"P" appears in the l.h. display area. The r.h. display area flashes.
4. Use ▲/▼ to select "12".
5. **OK** to confirm.
"1" flashes in the l.h. display area.
6. Use ▲/▼ to select "2".
7. **OK** to confirm.
The value of the selected maximum heating output, in % of the upper heating output, flashes in the r.h. display area.

Example:
■ $25 \pm 25\%$
■ $100 \pm 100\%$
8. Use ▲/▼ to select the required max. heating output.
9. **OK** to confirm. The selected value is adopted.
10. Check the selected heating output by measuring the gas throughput.



Matching the circulation pump rate to the heating system

In its delivered condition the circulation pump is set to the following values:

- **For DHW heating:** Speed 100 %
- **For heating mode without outside temperature sensor:**

Rated heating output in kW	19	26	30	35
Speed in %	72	80	86	100

The speed cannot be changed.

- **For heating mode with outside temperature sensor:**

Rated heating output in kW	19	26	30	35
Min. speed in %	72	72	72	72
Max. speed in %	72	80	86	100

The maximum speed can be changed. See the following chapter.




Fig. 22

- (A) Max. speed 19 kW
- (B) Max. speed 26 kW
- (C) Max. speed 30 kW
- (D) Max. speed 35 kW
- (E) Min. speed

Changing the maximum speed

Only when operating with an outside temperature sensor.

2. ▲/▼ until **CONF** flashes.

1. Tap **MODE**.



Matching the circulation pump rate to the... (cont.)

3. **OK** to confirm.
"P" appears in the l.h. display area. The r.h. display area flashes.
4. Use ▲/▼ to select "12".
5. **OK** to confirm.
"1" flashes in the l.h. display area.
6. Use ▲/▼ to select "6".
7. **OK** to confirm.
The selected max. speed in % will flash in the r.h. display area.
8. Use ▲/▼ to change the speed value.
Max. speed and setting range are subject to appliance-specific parameters.
9. **OK** to confirm. The selected value is adopted.



Matching the burner output to the flue system

To match the burner output to the system's flue pipe length, a correction factor can be set.

1. Tap **MODE**.
2. ▲/▼ until **CONF1** flashes.
3. **OK** to confirm.
"P" appears in the l.h. display area. The r.h. display area flashes.
4. Use ▲/▼ to select "12".
5. **OK** to confirm.
"1" flashes in the l.h. display area.
6. Use ▲/▼ to select "3".
7. **OK** to confirm.
The selected correction factor flashes in the r.h. display area.
8. Refer to the following table for the correction factor required for the connected flue system.
9. Use ▲/▼ to change the correction factor.
10. **OK** to confirm. The selected value is adopted.

Correction factor		1	2	3	4	5	6
Flue system	Rated heating output (kW)	Max. run length (m)					
Open flue operation Ø 60 mm	19	4	10	16	22	—	—
	26	2	8	13.5	18.5	22	25
	30	2	8	13.5	18.5	22	25
	35	5	12	18	23	—	—
Room sealed operation Ø 60/100 mm coaxial	19	2	6	10	13	16	19
	26	1	4	7	10	12	13.5
	30	1	4	7	10	12	13.5
	35	3	6	9	12	14	17



Burner adjustment when connecting multiple flues to a shared flue system

When connecting several Vitodens 100-W to a shared flue system:

Adjust the burner setting of each connected boiler by a correction factor to match the flue system.

System conditions:

- Shared flue in shaft Ø 100 mm
- Balanced flue connection line from boiler to shaft Ø 80/125 mm

- Minimum shaft cross-section
 - Square 175 x 175 mm
 - Round Ø 195 mm
- Height between floors min. 2.5 m
- Max. 6 boilers with the same rated heating output connected to the flue system



Burner adjustment when connecting multiple... (cont.)

1. Tap **MODE**.
2. ▲/▼ until **CONFI** flashes.
3. **OK** to confirm.
"P" appears in the l.h. display area. The r.h. display area flashes.
4. Use ▲/▼ to select "12".
5. **OK** to confirm.
"1" flashes in the l.h. display area.
6. Use ▲/▼ to select "4".
7. **OK** to confirm.
"0" flashes in the r.h. display area.
8. Refer to the following tables for the correction factor required for the flue system.
9. Use ▲/▼ to set the correction factor.
10. **OK** to confirm. The selected value is adopted.

One boiler per floor




Fig. 23

Rated heating output 19 kW – operation with natural gas

Number of boilers	2	3	4	5	6
Correction factor (setting value)	Flue length a (m)				
0					
1	≤ 25	≤ 13	≤ 10		
2	–	> 13 ≤ 25	> 10 ≤ 19	≤ 16	≤ 14
3	–	–	> 19 ≤ 25	> 16 ≤ 25	> 14 ≤ 21
4	–	–	–	–	> 21 ≤ 25
5	–	–	–	–	–
6	–	–	–	–	–



Burner adjustment when connecting multiple... (cont.)

Rated heating output 19 kW – operation with LPG

Number of boilers	2	3	4	5	6
Correction factor (setting value)	Flue length a (m)				
0					
1	≤ 25	≤ 20	≤ 13	≤ 12	
2	–	> 20 ≤ 25	> 13 ≤ 23	> 12 ≤ 18	≤ 15
3	–	–	> 23 ≤ 25	> 18 ≤ 25	> 15 ≤ 20
4	–	–	–	–	> 20 ≤ 25
5	–	–	–	–	–
6	–	–	–	–	–

Rated heating output 26 kW – operation with natural gas

Number of boilers	2	3	4	5	6
Correction factor (setting value)	Flue length a (m)				
0					
1	≤ 18	≤ 9			
2	> 18 ≤ 25	> 9 ≤ 21	≤ 13	≤ 12	
3	–	> 21 ≤ 25	> 13 ≤ 23	> 12 ≤ 18	≤ 16
4	–	–	> 23 ≤ 25	> 18 ≤ 25	> 16 ≤ 21
5	–	–	–	–	> 21 ≤ 25
6	–	–	–	–	–

Rated heating output 26 kW – operation with LPG

Number of boilers	2	3	4	5	6
Correction factor (setting value)	Flue length a (m)				
0					
1	≤ 25	≤ 12	≤ 10		
2	–	> 12 ≤ 25	> 10 ≤ 16	≤ 13	
3	–	–	> 16 ≤ 23	> 13 ≤ 17	≤ 15
4	–	–	> 23 ≤ 25	> 17 ≤ 22	> 15 ≤ 18
5	–	–	–	> 22 ≤ 25	> 18 ≤ 22
6	–	–	–	–	> 22 ≤ 25

Rated heating output 30 kW – operation with natural gas

Number of boilers	2	3	4	5	6
Correction factor (setting value)	Flue length a (m)				
0					
1	≤ 25	≤ 11	≤ 8		
2	–	> 11 ≤ 25	> 8 ≤ 17	≤ 14	≤ 13
3	–	–	> 17 ≤ 24	> 14 ≤ 18	> 13 ≤ 16
4	–	–	> 24 ≤ 25	> 18 ≤ 23	> 16 ≤ 19
5	–	–	–	> 23 ≤ 25	> 19 ≤ 25
6	–	–	–	–	–



Burner adjustment when connecting multiple... (cont.)

Rated heating output 30 kW – operation with LPG

Number of boilers	2	3	4	5	6
Correction factor (setting value)	Flue length a (m)				
0					
1	≤ 25	≤ 12	≤ 9		
2	–	> 12 ≤ 25	> 9 ≤ 16	≤ 13	
3	–	–	> 16 ≤ 22	> 13 ≤ 17	≤ 15
4	–	–	> 22 ≤ 25	> 17 ≤ 22	> 15 ≤ 19
5	–	–	–	> 22 ≤ 25	> 19 ≤ 22
6	–	–	–	–	> 22 ≤ 25

Rated heating output 35 kW – operation with natural gas

Number of boilers	2	3	4	5	6
Correction factor (setting value)	Flue length a (m)				
0					
1	≤ 19	≤ 9			
2	> 19 ≤ 25	> 9 ≤ 21	≤ 13	≤ 12	
3	–	> 21 ≤ 25	> 13 ≤ 18	> 12 ≤ 15	≤ 14
4	–	–	> 18 ≤ 25	> 15 ≤ 18	> 14 ≤ 16
5	–	–	–	> 18 ≤ 24	> 16 ≤ 20
6	–	–	–	> 24 ≤ 25	> 20 ≤ 23

Rated heating output 35 kW – operation with LPG

Number of boilers	2	3	4	5	6
Correction factor (setting value)	Flue length a (m)				
0					
1	≤ 22	≤ 10			
2	> 22 ≤ 25	> 10 ≤ 20	≤ 13	≤ 12	
3	–	> 20 ≤ 25	> 13 ≤ 17	> 12 ≤ 14	
4	–	–	> 17 ≤ 23	> 14 ≤ 18	≤ 16
5	–	–	> 23 ≤ 25	> 18 ≤ 21	> 16 ≤ 18
6	–	–	–	> 21 ≤ 24	> 18 ≤ 20

Note

The correction factor changes the boiler modulation range.



Two boilers per floor




Fig. 24

Rated heating output 19 kW – operation with natural gas

Number of boilers	2	4	6
Correction factor (setting value)	Flue length a (m)		
0			
1	≤ 25	≤ 6	
2	–	> 6 ≤ 16	≤ 9
3	–	> 16 ≤ 25	> 9 ≤ 16
4	–	–	> 16 ≤ 24
5	–	–	> 24 ≤ 25
6	–	–	–



Burner adjustment when connecting multiple... (cont.)

Rated heating output 19 kW – operation with LPG

Number of boilers	2	4	6
Correction factor (setting value)	Flue length a (m)		
0			
1	≤ 25	≤ 9	≤ 7
2	–	$> 9 \leq 20$	$> 7 \leq 11$
3	–	$> 20 \leq 25$	$> 11 \leq 15$
4	–	–	$> 15 \leq 21$
5	–	–	$> 21 \leq 25$
6	–	–	–

Rated heating output 26 kW – operation with natural gas

Number of boilers	2	4	6
Correction factor (setting value)	Flue length a (m)		
0			
1	≤ 16	≤ 4	
2	$> 16 \leq 25$	$> 4 \leq 10$	≤ 7
3	–	$> 10 \leq 20$	$> 7 \leq 11$
4	–	$> 20 \leq 25$	$> 11 \leq 15$
5	–	–	$> 15 \leq 20$
6	–	–	$> 20 \leq 24$

Rated heating output 26 kW – operation with LPG

Number of boilers	2	4	6
Correction factor (setting value)	Flue length a (m)		
0			
1	≤ 25	≤ 6	
2	–	$> 6 \leq 12$	≤ 8
3	–	$> 12 \leq 19$	$> 8 \leq 10$
4	–	$> 19 \leq 25$	$> 10 \leq 13$
5	–	–	$> 13 \leq 16$
6	–	–	$> 16 \leq 20$

Rated heating output 30 kW – operation with natural gas

Number of boilers	2	4	6
Correction factor (setting value)	Flue length a (m)		
0			
1	≤ 23	≤ 5	
2	$> 23 \leq 25$	$> 5 \leq 13$	≤ 8
3	–	$> 13 \leq 20$	$> 8 \leq 11$
4	–	$> 20 \leq 25$	$> 11 \leq 14$
5	–	–	$> 14 \leq 19$
6	–	–	$> 19 \leq 23$



Burner adjustment when connecting multiple... (cont.)

Rated heating output 30 kW – operation with LPG

Number of boilers	2	4	6
Correction factor (setting value)	Flue length a (m)		
0			
1	≤ 25	≤ 6	
2	–	$> 6 \leq 12$	≤ 8
3	–	$> 12 \leq 18$	$> 8 \leq 10$
4	–	$> 18 \leq 25$	$> 10 \leq 13$
5	–	–	$> 13 \leq 17$
6	–	–	$> 17 \leq 19$

Rated heating output 35 kW – operation with natural gas

Number of boilers	2	4	6
Correction factor (setting value)	Flue length a (m)		
0			
1	≤ 17	≤ 4	
2	$> 17 \leq 25$	$> 4 \leq 10$	≤ 7
3	–	$> 10 \leq 15$	$> 7 \leq 8$
4	–	$> 15 \leq 21$	$> 8 \leq 11$
5	–	$> 21 \leq 25$	$> 11 \leq 15$
6	–	–	$> 15 \leq 17$

Rated heating output 35 kW – operation with LPG

Number of boilers	2	4	6
Correction factor (setting value)	Flue length a (m)		
0			
1	≤ 20	≤ 5	
2	$> 20 \leq 25$	$> 5 \leq 9$	≤ 6
3	–	$> 9 \leq 14$	$> 6 \leq 8$
4	–	$> 14 \leq 20$	$> 8 \leq 10$
5	–	$> 20 \leq 25$	$> 10 \leq 13$
6	–	–	$> 13 \leq 15$

Note

The correction factor changes the boiler modulation range.



Adjust the burner setting if several boilers are connected to a shared flue (flue gas cascade)

Adjust the burner setting of each connected boiler by a correction factor to match the flue system.

System conditions:

- Shared flue gas header \varnothing 100 mm
- Max. 4 boilers with the same rated heating output connected to the flue system

1. Tap **MODE**.
2. $\blacktriangle/\blacktriangledown$ until **CONF1** flashes.
3. **OK** to confirm.
"P" appears in the l.h. display area. The r.h. display area flashes.
4. Use $\blacktriangle/\blacktriangledown$ to select "12".
5. **OK** to confirm.
"1" flashes in the l.h. display area.
6. Use $\blacktriangle/\blacktriangledown$ to select "4".



Adjust the burner setting if several boilers... (cont.)

7. **OK** to confirm.
"0" flashes in the r.h. display area.
8. Refer to the following tables for the correction factor required for the flue system.
9. Use ▲/▼ to set the correction factor.
10. **OK** to confirm. The selected value is adopted.




Fig. 25

Rated heating output 19 kW – operation with natural gas

Number of boilers	2	3	4
Correction factor (setting value)	Flue length a (m)		
0			
1	≤ 25	≤ 8	
2	–	> 8 ≤ 25	≤ 13
3	–	–	> 13 ≤ 25
4	–	–	–
5	–	–	–
6	–	–	–

Rated heating output 19 kW – operation with LPG

Number of boilers	2	3	4
Correction factor (setting value)	Flue length a (m)		
0			
1	≤ 25	≤ 16	≤ 6
2	–	> 16 ≤ 25	> 6 ≤ 17
3	–	–	> 17 ≤ 25
4	–	–	–
5	–	–	–
6	–	–	–



Adjust the burner setting if several boilers... (cont.)

Rated heating output 26 kW – operation with natural gas

Number of boilers	2	3	4
Correction factor (setting value)	Flue length a (m)		
0			
1	≤ 16	≤ 4	
2	$> 16 \leq 25$	$> 4 \leq 16$	≤ 6
3	–	$> 16 \leq 25$	$> 6 \leq 17$
4	–	–	$> 17 \leq 25$
5	–	–	–
6	–	–	–

Rated heating output 26 kW – operation with LPG

Number of boilers	2	3	4
Correction factor (setting value)	Flue length a (m)		
0			
1	≤ 25	≤ 8	≤ 3
2	–	$> 8 \leq 21$	$> 3 \leq 9$
3	–	$> 21 \leq 25$	$> 9 \leq 16$
4	–	–	$> 16 \leq 23$
5	–	–	$> 23 \leq 25$
6	–	–	–

Rated heating output 30 kW – operation with natural gas

Number of boilers	2	3	4
Correction factor (setting value)	Flue length a (m)		
0			
1	≤ 24	≤ 6	
2	$> 24 \leq 25$	$> 6 \leq 23$	≤ 10
3	–	$> 23 \leq 25$	$> 10 \leq 17$
4	–	–	$> 17 \leq 24$
5	–	–	$> 24 \leq 25$
6	–	–	–

Rated heating output 30 kW – operation with LPG

Number of boilers	2	3	4
Correction factor (setting value)	Flue length a (m)		
0			
1	≤ 25	≤ 8	
2	–	$> 8 \leq 21$	≤ 9
3	–	$> 21 \leq 25$	$> 9 \leq 15$
4	–	–	$> 15 \leq 23$
5	–	–	$> 23 \leq 25$
6	–	–	–



Adjust the burner setting if several boilers... (cont.)

Rated heating output 35 kW – operation with natural gas

Number of boilers	2	3	4
Correction factor (setting value)	Flue length a (m)		
0			
1	≤ 18	≤ 4	
2	$> 18 \leq 25$	$> 4 \leq 16$	≤ 6
3	–	$> 16 \leq 25$	$> 6 \leq 11$
4	–	–	$> 11 \leq 17$
5	–	–	$> 17 \leq 25$
6	–	–	–

Rated heating output 35 kW – operation with LPG

Number of boilers	2	3	4
Correction factor (setting value)	Flue length a (m)		
0			
1	≤ 21	≤ 5	
2	$> 21 \leq 25$	$> 5 \leq 15$	≤ 6
3	–	$> 15 \leq 23$	$> 6 \leq 10$
4	–	$> 23 \leq 25$	$> 10 \leq 16$
5	–	–	$> 16 \leq 22$
6	–	–	$> 22 \leq 25$

Note

The correction factor changes the boiler modulation range.



Checking the CO₂ content

The Vitodens 100-W is factory-set for natural gas. During commissioning or maintenance, the CO₂ and CO have to be measured at the boiler flue adaptor test port to check the flue integrity. Subject to the Wobbe index, the CO₂ content fluctuates between 7.5 % and 10.5 %. CO of up to 500 ppm during start-up is acceptable. We recommend measuring O₂, as the value is unmistakable regarding lambda (air/gas). The O₂ content fluctuates between 7.5 % and 3.2 %. The CO/CO₂ ratio has to be less than 0.004. If the actual CO₂ or O₂ and CO values deviate from the stated range, check the balanced flue system for leaks. If flue installation is OK, change the gas valve.

Note

Operate the appliance with uncontaminated combustion air to prevent operating faults and damage.




Fig. 26

1. Connect a flue gas analyser at flue gas port (A) on the boiler flue connection.
2. Start the boiler and check for leaks.



Danger

Escaping gas leads to a risk of explosion. Check all gas equipment for tightness.



Checking the CO₂ content (cont.)

3. To check the CO₂ content the burner output can be adjusted manually.

1. Tap **MODE**.

2. Press ▲/▼ until **"SERV"** is displayed.

3. **OK** to confirm.

OFF appears on the display. Test mode is then not activated.

4. Use ▲/▼ to select the burner output:

Shown on the Display	Burner output
OFF	0 %
— 20	20 %
— — 40	40 %
— — — 60	60 %
— — — — 80	80 %
— — — — — 100	100 %

5. Confirm your settings with **OK**.

The bars stop flashing.

4. Check the CO₂ content for the upper heating output (100 %).

For CO₂ content limits, see page 23.

5. Check the CO₂ content for the lower heating output (20 %).

The CO₂ content must be between 0.3 and 0.9 % below the value of the upper heating output.

6. ■ If the CO₂ content lies within the indicated range, continue with point 8.

- If the CO₂ content lies **outside** the indicated range, check the flue gas/ventilation air system for tightness; remedy any leaks.
Replace gas train if required.

7. Re-check the CO₂ content for the higher and lower heating output.

8. Terminate test mode:

1. ▲/▼ until **"SERV"** flashes.

2. **OK** to confirm.

The selected value flashes.

3. ▼ until **OFF** flashes.

4. **OK** to confirm.

When **"SERV"** disappears, test mode is terminated.

9. Shut down the boiler, remove the flue gas analyser and close flue gas test port (A).



Removing the burner




Fig. 27

1. Switch off the power supply.
2. Shut off the gas supply.
3. Pull the power cables from fan motor (A), gas train (B) and electrodes (C).
4. Pull venturi extension (D) from the fan.
5. Undo gas supply pipe fitting (E).
6. Undo 4 screws (F) and remove the burner.



Please note

To prevent damage:
Never rest the burner on the burner gauze assembly.



Checking the burner gasket and burner gauze assembly

Check burner gasket (A) for damage and replace if required.

Replace the burner gauze assembly if it is damaged.



Checking the burner gasket and burner gauze... (cont.)




Fig. 28

1. Remove electrode (B).
2. Undo 2 Torx screws and remove thermal insulation ring (C).
3. Undo 2 Torx screws and remove burner gauze assembly (D) with gasket (E).
4. Insert and secure new burner gauze assembly (D) with new gasket (E).

! Please note
Tighten screws just enough to ensure the components do not suffer damage and will function correctly.

5. Mount thermal insulation ring (C).

! Please note
Tighten screws just enough to ensure the components do not suffer damage and will function correctly.

6. Fit electrode (B).

! Please note
Tighten screws just enough to ensure the components do not suffer damage and will function correctly.



Checking and adjusting the electrode

1. Check the electrode for wear and contamination.
2. Clean the electrode with a small brush (not with a wire brush) or emery paper.



Checking and adjusting the electrode (cont.)





Fig. 29

3. Check the electrode gaps. If the gaps are not as specified or the electrode is damaged, replace electrode and gasket and realign the electrode.



Please note

Tighten screws just enough to ensure the components do not suffer damage and will function correctly.



Cleaning the heat exchanger



Please note

Scratches to the surfaces of the heat exchanger that come into contact with hot gas can result in corrosion damage.

Never use brushes to clean the heat exchanger.



Please note

Brushing can cause deposits to become lodged in the gaps between the coils.

Never use brushes to clean the heat exchanger.

Note

Discolouration on the heat exchanger surface is a normal sign of use. It has no bearing on the function and service life of the heat exchanger.

The use of chemical cleaning agents is not required.




Fig. 30

1. Use a vacuum cleaner to remove combustion residues from heating surface (A) of the heat exchanger.
2. Flush heating surface (A) with water.
3. Check condensate drain and clean trap. See the following chapter.
4. Flush the heating surface again with water. This will also fill the trap with water.



Checking the condensate drain and cleaning the trap




Fig. 31

1. Pull trap (A) upwards out of the drain connection.
2. Pull supply hose (B) off trap (A).
3. Clean trap (A).
4. Reconnect supply hose (B).
5. Refit trap (A) to the drain connection.
6. Fill trap (A) with water. For this, pour approx. 0.3 l of water into the combustion chamber.
7. Check that condensate can drain freely and that the connections are tight.



Installing the burner




Fig. 32

1. Fit burner and tighten 4 screws (A) diagonally.



Please note

Tighten screws just enough to ensure the components do not suffer damage and will function correctly.

2. Insert new gasket and tighten the fitting on gas supply pipe (B).
3. Plug venturi extension (C) onto the fan.
4. Fit electrical cables to fan motor (D), gas train (E) and ignition unit (F).



Installing the burner (cont.)

5. Reopen gas supply and switch on power supply.

6. Check gas connections for tightness.



Danger

Escaping gas leads to a risk of explosion.
Check the fitting for gas tightness.



Please note

The use of leak detection spray can result in faulty operation.
Leak detection spray must not come into contact with electrical contacts or seal the diaphragm opening on the gas valve.



Checking the diaphragm expansion vessel and system pressure

Note

The expansion vessel can lose some of its charge pressure over time. When the boiler heats up, the pressure gauge will indicate a higher pressure of 2 or 3 bar (0.2 or 0.3 MPa). The safety valve may also respond and discharge the excess pressure. Therefore check the expansion vessel pre-charge pressure annually.

Check whether the installed expansion vessel is adequate for the system water volume (GB only). Carry out this test on a cold system.

1. Drain the system until the pressure gauge shows "0".
Alternatively, close the cap valve on the expansion vessel and reduce the pressure until the pressure gauge indicates "0".
2. If the pre-charge pressure of the expansion vessel is lower than the static system pressure, top up with nitrogen until the pre-charge pressure is 0.1 to 0.2 bar (10 to 20 kPa) higher than the static system pressure.
3. Top up with water until the charge pressure of the cooled system is at least 1.0 bar (0.1 MPa), and is 0.1 to 0.2 bar (10 to 20 kPa) higher than the pre-charge pressure of the expansion vessel.
Permiss. operating pressure: 3 bar (0.3 MPa)

Note

The gas condensing combi boiler can be topped up by opening top-up valve (A).




Fig. 33



Checking all connections on the heating water side and DHW side for leaks



Checking the flue system for unrestricted flow and tightness



Checking the firm seating of electrical connections



Checking all gas equipment for tightness at operating pressure



Danger

Escaping gas leads to a risk of explosion.
Check all gas equipment for tightness.



Please note

The use of leak detection spray can result in faulty operation.
Leak detection spray must not come into contact with electrical contacts or seal the diaphragm opening on the gas valve.



Mounting the front panel




Fig. 34

1. Hook the front panel into place.

2. Tighten screws underneath.



Setting the DHW comfort function

Only possible for gas condensing combi boiler. The comfort function makes DHW available faster at the selected set DHW temperature.

1. Turn ON the ON/OFF switch.

2. Tap **MODE**.

3. ▲/▼ until **CONF** flashes.

4. **OK** to confirm.

"P" appears in the l.h. display area. The r.h. display area flashes.

5. Use ▲/▼ to select "12".

6. **OK** to confirm.

"1" flashes in the l.h. display area.

7. Use ▲/▼ to select "12".



Setting the DHW comfort function (cont.)

8. **OK** to confirm.
"0" flashes in the r.h. display area.
9. Use ▲/▼ to select the comfort function.
 - "0": Without comfort function
or
 - "1": With comfort function
10. **OK** to confirm.



Setting display backlight for standby

1. Turn ON the ON/OFF switch.
2. Tap **MODE**.
3. ▲/▼ until **CONF1** flashes.
4. **OK** to confirm.
"P" appears in the l.h. display area. The r.h. display area flashes.
5. Use ▲/▼ to select "12".
6. **OK** to confirm.
"1" flashes in the l.h. display area.
7. Use ▲/▼ to select "10".
8. **OK** to confirm.
"0" flashes in the r.h. display area.
9. Use ▲/▼ to select the display backlight.
 - "0": Display backlight dimmed
or
 - "1": Display backlight off
10. **OK** to confirm.



Setting display contrast

1. Turn ON the ON/OFF switch.
2. Tap **MODE**.
3. ▲/▼ until **CONF1** flashes.
4. **OK** to confirm.
"P" appears in the l.h. display area. The r.h. display area flashes.
5. Use ▲/▼ to select "12".
6. **OK** to confirm.
"1" flashes in the l.h. display area.
7. Use ▲/▼ to select "11".
8. **OK** to confirm.
"3" flashes in the r.h. display area.
9. Use ▲/▼ to adjust the display contrast.
Adjustable from 0 to 6. The higher the value, the greater the contrast.
10. **OK** to confirm.



Setting the signal tone for display operation

1. Turn ON the ON/OFF switch.
2. Tap **MODE**.
3. ▲/▼ until **CONF1** flashes.
4. **OK** to confirm.
"P" appears in the l.h. display area. The r.h. display area flashes.
5. Use ▲/▼ to select "12".
6. **OK** to confirm.
"1" flashes in the l.h. display area.
7. Use ▲/▼ to select "9".
8. **OK** to confirm.
"0" flashes in the r.h. display area.



Setting the signal tone for display operation (cont.)

9. Use ▲/▼ to set the signal tone.
 - "0": Signal tone on
 - or
 - "1": Signal tone off
10. **OK** to confirm.



Instructing the system user

The system installer should hand the operating instructions to the system user and instruct the user in operating the system.



Converting from operation with LPG to operation with natural gas




Fig. 35

1. Pull cable from gas train (A).
2. Undo union nut (B) and remove gas gasket.
3. Undo 2 screws (C) and remove gas train (A).
4. Remove gas restrictor (D) for LPG and gasket (E) from gas train (A).
5. Insert new gasket (E) in gas train (A).
If the gasket is missing, order the appropriate conversion kit as an individual part. See parts list (burner assembly).
6. Mount gas train (A) with new gas gasket (F).
Torque for fixing screws (C): 6 Nm
Torque for union nut (B): 30 Nm
7. Remove or void gas type sticker on the top of the boiler (next to the type plate).
8. Start the boiler and check for leaks.



Danger

Escaping gas leads to a risk of explosion.
Check all gas equipment for tightness.



Please note

The use of leak detection spray can result in faulty operation.
Leak detection spray must not come into contact with electrical contacts or seal the diaphragm opening on the gas valve.

Changing the gas type at the control unit


1. Turn ON the ON/OFF switch.
2. Tap **MODE**.
3. ▲/▼ until **CONF1** flashes.
4. **OK** to confirm.
"P" appears in the l.h. display area. The r.h. display area flashes.
5. Use ▲/▼ to select "12".
6. **OK** to confirm.
"1" flashes in the l.h. display area.
7. Use ▲/▼ to select "5".
8. **OK** to confirm.
"1" flashes in the r.h. display area.
9. Use ▲/▼ to switch the control unit to **"0"** (operation with natural gas).
10. **OK** to confirm.
11. Turn the ON/OFF switch OFF and ON again.
The selected operating mode is saved.

Checking the CO₂ content

See page 35.

Function sequence and possible faults

Diagnosis



Fault display






Fig. 36

In case of a fault, the display will show  and the fault code.
If  flashes and "R" appears, the burner is locked.
See page 48.
For an explanation of the fault codes, see the following table.

Fault display (cont.)

Fault code displayed	System characteristics	Cause	Measures
0A	Burner blocked	CO limiter (if installed) has responded. CO concentration too high.	Check the heating system. Remove the cause of escaping CO.
0A	Burner blocked	Gas pressure switch (if installed) has responded. Gas pressure too low.	Check the gas supply.
0C	Burner blocked	Mains voltage too low	Check the power supply.
10	Continuous operation	Short circuit, outside temperature sensor	Check the outside temperature sensor and lead (see page 50).
18	Continuous operation	Lead break, outside temperature sensor	Check the outside temperature sensor and lead (see page 50).
30	Burner blocked	Short circuit, boiler water temperature sensor	Check boiler water temperature sensor (see page 51).
38	Burner blocked	Lead break, boiler water temperature sensor	Check boiler water temperature sensor (see page 51).
50	No DHW heating	Short circuit, cylinder temperature sensor	Check sensor (see page 52).
51	No DHW heating	Short circuit, outlet temperature sensor	Check sensor (see page 53).
52	Burner blocked	Short circuit, flow sensor	Check connections and lead; replace sensor if required.
58	No DHW heating	Lead break, cylinder temperature sensor	Check sensor (see page 52).
59	No DHW heating	Lead break, outlet temperature sensor	Check sensor (see page 53).
5A	Burner blocked	Lead break, flow sensor	Check connections and lead; replace sensor if required.
A3	Burner blocked.	Flue gas temperature sensor incorrectly positioned.	Fit flue gas temperature sensor correctly (see page 55).
A9	Control mode without OpenTherm device	Communication error, OpenTherm device	Check connections and lead; replace OpenTherm device if required.
b0	Burner blocked	Short circuit, flue gas temperature sensor	Check sensor (see page 54).
b7	Emergency mode	Burner control unit fault	Turn the ON/OFF switch OFF and ON again.
b8	Burner blocked	Lead break, flue gas temperature sensor	Check sensor (see page 54).
E3	Burner in a fault state	Fault in safety chain	Check the temperature limiter and connecting cables (see page 53). Check the control unit, and replace if required.
E5	Burner blocked	Internal fault	Check the ionisation electrode and connecting cables. Press reset (see page 48).
F0	Burner blocked.	Internal fault	Replace control unit.
F1	Burner in a fault state	Max. flue gas temperature exceeded	Check heating system fill level. Check circulation pump. Vent the system. Press reset (see page 48).

Fault display (cont.)

Fault code displayed	System characteristics	Cause	Measures
F2	Burner in a fault state	Temperature limiter has responded	Check heating system fill level. Check circulation pump. Vent the system. Check the temperature limiter and connecting cables (see page 53). Press reset (see page 48).
F3	Burner in a fault state	Flame signal is already present at burner start	Check ionisation electrode and connecting cable. Press reset (see page 48).
F4	Burner in a fault state	No flame signal detected	Check the ignition/ionisation electrode and connecting cables, check the gas pressure, check the gas train, ignition, ignition module and condensate drain. Press reset (see page 48).
F8	Burner in a fault state	Fuel valve closes too late	Check gas train. Check both control paths. Press reset (see page 48).
F9	Burner in a fault state	Fan speed too low during burner start	Check fan, fan connecting cables and power supply to fan; check fan control. Press reset (see page 48).
FA	Burner in a fault state	Fan idle state not reached	Check fan, fan connecting cables and fan control. Press reset (see page 48).
FC	Burner blocked	Electrical fan control (control unit) faulty	Check fan connecting cable; replace if required, or replace control unit
Fd	Burner blocked	Burner control unit fault	Check ignition electrodes and connecting cables. Check whether a strong interference (EMC) field exists near the appliance. Press reset (see page 48). Replace control unit if fault persists.
FF	Burner blocked	Burner control unit fault	Check ignition electrodes and connecting cables. Check whether a strong interference (EMC) field exists near the appliance. Press reset (see page 48). Replace control unit if fault persists.

Reset activation (reset burner control unit)

Touch **R** for approx. 2 s.

If the fault has been removed, the fault symbol "△" disappears and the default display is shown or a further fault message is displayed.

If the fault persists, the fault message appears again.

Repairs



Please note

Residual water will escape when the boiler or one of the following components is fitted or removed:

- Water-filled pipework
- Circulation pumps
- Plate heat exchanger
- Components fitted in the heating water or DHW circuit

Water ingress can result in damage to other components.

Protect the following components against ingress of water:

- Control unit (in particular in the service position)
- Electrical components
- Plug-in connections
- Cables and leads

Removing the front panel




Fig. 37

1. Undo screws underneath the boiler; do not remove completely.
2. Remove the front panel.

Outside temperature sensor




Fig. 38




Fig. 39 Sensor type: NTC 10 kΩ

1. Open the control unit enclosure. See page 15.
2. Disconnect leads from outside temperature sensor.

3. Check the sensor resistance and compare it to the curve.
4. In the event of severe deviation replace the sensor.

Repairs (cont.)

Boiler water temperature sensor




Fig. 40




Fig. 41

1. Pull out the leads at boiler water temperature sensor **A** and check the resistance.

2. Check the sensor resistance and compare it to the curve.
3. In the case of severe deviation, drain the boiler on the heating water side and replace the sensor.



Danger

The boiler water temperature sensor is directly immersed in the heating water (risk of scalding).

Drain the boiler before replacing the sensor.

Checking the cylinder temperature sensor (gas condensing boiler)




Fig. 42

1. Remove plugs **5** from the cable harness and check the resistance.




Fig. 43

2. Compare the sensor resistance with the curve.
3. In the event of severe deviation replace the sensor.

Repairs (cont.)

Checking the temperature limiter

If the burner control unit cannot be reset after a fault shutdown although the boiler water temperature is below approx. 95 °C, check the temperature limiter.




Fig. 44

1. Pull out the leads at temperature limiter (A).
2. Check the continuity of the temperature limiter with a multimeter.
3. Remove faulty temperature limiter.
4. Install a new temperature limiter.
5. Reset by pressing "Reset" (see page 48).

Checking the outlet temperature sensor (gas condensing combi boiler)




Fig. 45

1. Pull leads from outlet temperature sensor (A).
2. Check the sensor resistance and compare it to the curve.




Fig. 46

3. In the event of severe deviation replace the sensor.

Note

Water may leak out when replacing the outlet temperature sensor. Shut off the cold water supply. Drain the DHW line and the plate heat exchanger (on the DHW side).

Checking the flue gas temperature sensor




Fig. 47

1. Undo nut (A) and remove expansion vessel (B).
2. Pull leads from flue gas temperature sensor (C).
3. Check the sensor resistance and compare it to the curve.

Repairs (cont.)




Fig. 48

Fault "A3" during commissioning

During commissioning, the control unit checks whether the flue gas temperature sensor is correctly positioned. If the flue gas temperature sensor is incorrectly positioned, commissioning is aborted and fault message A3 is shown.

1. Check whether the flue gas temperature sensor is correctly inserted. See previous diagram.
2. If necessary, correct the position of the flue gas temperature sensor or replace faulty flue gas temperature sensor.
3. Touch **R** for approx. 2 s and repeat commissioning. The check is repeated until it is completed successfully.

Replacing the flow limiter (gas condensing combi boiler)




Fig. 49

1. Drain the boiler on the DHW side.
2. Pivot the control unit downwards.
3. Undo screws (A).
4. Remove cap (B).
5. Select new flow limiter (C) according to the boiler serial no. (see type plate) and the following table.
6. Insert new flow limiter (C).
7. Mount new cap (B) provided.

Serial no. (type plate)	Flow rate l/min	Colour
7570673	10	Black
7570675	12	Red
7570677	14	Brown

Checking or replacing the plate heat exchanger (gas condensing combi boiler)




Fig. 50

- Ⓒ Heating water flow
- Ⓓ Heating water return

- Ⓔ Cold water
- Ⓕ DHW

1. Shut off and drain the boiler on the heating water and the DHW side.
2. Pivot the control unit downwards.
3. Undo 2 screws Ⓐ on plate heat exchanger Ⓑ and remove plate heat exchanger with gaskets.

Note


During and after removal, small amounts of water may trickle from the plate heat exchanger.

4. Check the connections on the DHW side for scaling; clean or replace the plate heat exchanger if required.

5. Check the connections on the heating water side for contamination; clean or replace the plate heat exchanger if required.
6. Install in reverse order using new gaskets.

Note

During installation, ensure the fixing holes are aligned and the gaskets are seated correctly. Mount the plate heat exchanger with the correct orientation.

Repairs (cont.)**Checking the fuse***Fig. 51*

1. Switch off the power supply.
2. Open control unit enclosure (see page 15).
3. Check fuse F4.

Overview of assemblies

The following details are required when ordering parts:

- Serial no. (see type plate (A))
- Assembly (from this parts list)
- Position number of the individual part within the assembly (from this parts list)




Fig. 52

- | | |
|------------------------------------|---------------------------|
| (A) Type plate | (D) Control unit assembly |
| (B) Casing assembly | (E) Miscellaneous |
| (C) Heat cell assembly with burner | (F) Hydraulic assembly |

Casing assembly

Components




Fig. 53

Casing assembly (cont.)

Pos.	Part
0001	Front panel
0002	Profiled seal
0003	Viessmann logo
0004	Strain relief, upper part
0005	Air box floor
0006	Diaphragm grommets (set)
0007	Wall mounting bracket
0008	Vitodens 100 logo

Heat cell assembly




Fig. 54

Heat cell assembly (cont.)

Pos.	Part
0001	Gasket DN 60
0002	Boiler flue connection
0003	Plug for boiler flue connection
0004	Flue gasket
0005	Flue gas temperature sensor
0006	Heat exchanger
0007	Condensate hose
0008	Splash trap
0009	Tee union
0010	Gas connection
0011	Gasket A 17 x 24 x 2 (5 pce)
0012	Burner
0013	Thermal insulation block
0014	Heat exchanger mounting (set)
0015	O-ring 20.63 x 2.62 (5 pce)
0016	Condensate hose 400
0017	Corrugated hose 19 x 800 with ferrule/bend

Burner assembly




Fig. 55

Burner assembly (cont.)

Pos.	Part
0001	Burner gasket (wearing part)
0002	Thermal insulation ring
0003	Cylinder burner gauze assembly (wearing part)
0004	Gasket, burner gauze assembly
0005	Burner door
0006	Gasket, ionisation electrode (5 pce)
0007	Ignition/ionisation electrode
0008	Gasket, burner door flange (wearing part)
0009	Mounting bracket, thermal insulation ring (2 pce)
0010	Radial fan NRG 118
0011	Gas valve
0012	Conversion kit G31
0013	Venturi extension
0014	Gasket A 17 x 24 x 2 (5 pce)

Hydraulic assembly




Fig. 56

Components

Hydraulic assembly (cont.)

Pos.	Part
0001	Diaphragm expansion vessel CRI 8
0002	Diaphragm expansion vessel padding profile
0003	Gasket A 10 x 15 x 1.5 (5 pce)
0004	Diaphragm expansion vessel connection line G 3/8
0005	Connection elbow HR
0006	Profile hose HR
0007	Spring clip DN 25 (5 pce)
0008	Clip Ø 10 (5 pce)
0009	Clip Ø 8 narrow (5 pce)
0010	O-Ring 20.63 x 2.62 (5 pce)
0011	Air vent valve G 3/8
0012	Temperature sensor
0013	Circular seal washer 8 x 2 (5 pce)
0014	Profile hose HF
0015	Clip Ø 18 (5 pce)
0016	O-Ring 17 x 4 (5 pce)
0017	Pressure gauge
0018	Clip Ø 8 (5 pce)
0019	Adaptor, hose connector
0020	Thermal circuit breaker
0021	Connection elbow HF
0022	Hydraulics (see hydraulic assembly, system or combi boiler)
0023	Hose 10 x 1.5 x 1500

Hydraulic assembly, system boiler




Fig. 57

Hydraulic assembly, system boiler (cont.)

Pos.	Part
0001	Air vent valve
0002	O-Ring 34 x 3 (5 pce)
0003	Check valve
0004	O-Ring 23.7 x 3.6 (5 pce)
0005	Bypass cartridge
0006	Clip Ø 16 (5 pce)
0007	Stepper motor adaptor
0008	O-Ring 19.8 x 3.6 (5 pce)
0009	O-Ring 16 x 3 (5 pce)
0010	Clip Ø 18 (5 pce)
0011	Linear stepper motor
0012	Motor, circulation pump UPM3 15-75
0013	Safety valve
0014	Hydraulic assembly, system boiler

Hydraulic assembly, combi boiler




Fig. 58

Hydraulic assembly, combi boiler (cont.)

Pos.	Part
0001	Air vent valve for HC pump
0002	O-rings 34 x 3 (5 pce)
0003	O-Ring 23.7 x 3.6 (5 pce)
0004	Linear stepper motor
0005	Bypass cartridge
0006	Clip Ø 16 (5 pce)
0007	Stepper motor adaptor
0008	O-Ring 19.8 x 3.6 (5 pce)
0009	O-Ring 16 x 3 (5 pce)
0010	Clip Ø 18 (5 pce)
0011	Clip Ø 10 (5 pce)
0012	Check valve
0013	Temperature sensor
0014	Clip Ø 8 narrow (5 pce)
0015	Water volume controller
0016	Oval cap seal (5 pce)
0017	Gasket set PWT
0018	Flow sensor
0019	O-ring 9.6 x 2.4 (5 pce)
0020	Expansion vessel
0021	Motor, circulation pump UPM3 15-75
0022	Plate heat exchanger
0023	Safety valve
0024	Hydraulic assembly, combi boiler
0025	Clip Ø 8 (5 pce)
0026	Circular seal washer 8 x 2 (5 pce)

Control unit assembly

Components




Fig. 59

Control unit assembly (cont.)

Pos.	Part
0001	Cover, wiring chamber
0002	Clip hinge
0003	Profiled seal
0004	VBC113-D20 control unit
0005	Cable harness X20
0006	Ignition cable
0007	Gas valve connecting cable 35
0008	Fan connecting cable 100
0009	Cable harness, stepper motor AMP-X
0010	Fuse, 2.5 A (slow), 250 V (10 pce)
0011	Outside temperature sensor NTC
0012	Cable harness X21
0013	Connecting cable, heating circuit pump 20

Miscellaneous




Fig. 60

Miscellaneous (cont.)

Pos.	Part
0001	Touch-up spray paint, white, 150 ml can
0002	Touch-up paint stick, white
0003	Special grease
0004	Installation and service instructions
0005	Operating instructions



Functions and operating conditions in weather-compensated mode

In weather-compensated mode, the boiler water temperature is regulated subject to the outside temperature.

Heating curve for weather-compensated control




Fig. 61

- ⊗ Code for selected heating curve
The setting can be made in increments of - - to 35.

Set heating curve

1. Tap ▲/▼.
The set parameter flashes and  will be displayed.

2. Use ▲/▼ to select the parameter.

3. **OK** to confirm.

Frost protection function

The frost protection function requires an outside temperature sensor to be connected. The frost protection function becomes active at outside temperatures of < 5 °C. The burner starts and the boiler water temperature is held at 20 °C.

5697 787 GB



- | | | | |
|-------|---|-----|---|
| (A) | Diverter valve stepper motor | 1 | Outside temperature sensor (accessories) |
| (B) | Ignition/ionisation | 3 | Boiler water temperature sensor |
| (C) | Vitotrol 100 type UTA or on-site room temperature controller (switched 230 V input) | 4 | Outlet temperature sensor (gas condensing combi boiler) |
| (D) | Vitotrol 100, type UTDB or on-site room temperature controller (switched 230 V input) | 5 | Cylinder temperature sensor (gas condensing boiler) |
| (E) | Power supply 230 V/50 Hz | 15 | Flue gas temperature sensor |
| (F) | Remote control (OpenTherm device) or mixer extension kit (OpenTherm) | 20 | Circulation pump 230 V~ |
| (G) | Time switch (accessory) | 35 | Gas solenoid valve |
| (H) | Vitotrol 100, type UTDB-RF2 | 47 | Temperature limiter |
| (K) | Gas pressure switch (accessories) | 100 | Fan motor 230 V~ |
| X ... | Electrical interface | 100 | A Fan control |
| | | 149 | Flow sensor |

Reports

(cont.)

Settings and test values		Commis-	Mainte-	Mainte-	Mainte-	Mainte-
		sioning	nance/ service	nance/ service	nance/ service	nance/serv- ice
Date						
Signature						
Gas type	G					
Static pressure	<i>mbar</i> <i>kPa</i>					
Supply pressure (flow pres- sure)	<i>mbar</i> <i>kPa</i>					
Carbon dioxide content CO ₂						
▪ Upper heating output	% by vol.					
▪ Lower heating output	% by vol.					
Oxygen content O ₂						
▪ Upper heating output	% by vol.					
▪ Lower heating output	% by vol.					
Carbon monoxide content CO	<i>ppm</i>					

Specification

Gas condensing boiler, class II_{2H3P}

Type		B1HC			
Rated heating output range in heating mode					
T_F/T_R 50/30 °C	kW	4.7 (6.5)^{*1} – 19	4.7 (6.5)^{*1} – 26	5.9 (8.8)^{*1} – 30	5.9 (8.8)^{*1} – 35
T_F/T_R 80/60 °C	kW	4.3 (5.9)^{*1} – 17.4	4.3 (5.9)^{*1} – 23.8	5.4 (8.0)^{*1} – 27.5	5.4 (8.0)^{*1} – 32.1
Rated heating input range	kW	4.4 (6.1)^{*1} – 17.8	4.4 (6.1)^{*1} – 24.3	5.5 (8.2)^{*1} – 28.0	5.5 (8.2)^{*1} – 32.7
Connection values					
Relative to the max. load for:					
- Natural gas H	m ³ /h	1.88	2.6	2.96	3.46
- LPG P	kg/h	1.39	1.90	2.19	2.56
Rated voltage	V	230			
Rated frequency	Hz	50			
Rated current	A	2.0			
Backup fuse (max.)	A	16			
Power consumption (max.)	W	84	88	98	106
Permissible ambient temperature					
- during operation	°C	0 to +40			
- during storage and transport	°C	-20 to +65			
IP rating		IP X4 to EN 60529 (only for room sealed operation)			
Protection class		I			
Temperature limiter setting	°C	100 (fixed)			
Weight	kg	35	36	37	37
Product ID		CE-0063CQ3356			

Gas condensing combi boiler, class II_{2H3P}

Type		B1KC		
Rated heating output range in heating mode				
T_F/T_R 50/30 °C	kW	4.7 (6.5)^{*1} – 26	5.9 (8.8)^{*1} – 30	5.9 (8.8)^{*1} – 35
T_F/T_R 80/60 °C	kW	4.3 (5.9)^{*1} – 23.8	5.4 (8.0)^{*1} – 27.5	5.4 (8.0)^{*1} – 32.1
Rated heating output range for DHW heating	kW	4.3 (5.9)^{*1} – 26.0	5.4 (8.0)^{*1} – 30.0	5.4 (8.0)^{*1} – 35.0
Rated heating input range	kW	4.4 (6.1)^{*1} – 27.1	5.5 (8.2)^{*1} – 31.3	5.5 (8.2)^{*1} – 36.5
Connection values				
Relative to the max. load for:				
- Natural gas H	m ³ /h	2.87	3.31	3.86
- LPG P	kg/h	2.12	2.45	2.85

*1 Only when operating with LPG P

Specification

Specification (cont.)

Type		B1KC		
Rated heating output range in heating mode				
T_F/T_R 50/30 °C	kW	4.7 (6.5)^{*1} – 26	5.9 (8.8)^{*1} – 30	5.9 (8.8)^{*1} – 35
T_F/T_R 80/60 °C	kW	4.3 (5.9)^{*1} – 23.8	5.4 (8.0)^{*1} – 27.5	5.4 (8.0)^{*1} – 32.1
Rated voltage	V	230		
Rated frequency	Hz	50		
Rated current	A	2.0		
Backup fuse (max.)	A	16		
Power consumption (max.)	W	92	98	115
Permissible ambient temperature				
- during operation	°C	0 to +40		
- during storage and transport	°C	-20 to +65		
IP rating		IP X4 to EN 60529 (only for room sealed operation)		
Protection class		I		
Temperature limiter setting	°C	100 (fixed)		
DHW heating				
Permiss. operating pressure	bar	10	10	10
	MPa	1.0	1.0	1.0
Nominal water flow rate at ΔT 30 K (to EN 13203)	l/min	12.4	14.3	16.7
Set flow rate (max.)	l/min	10	12	14
Weight	kg	36	38	38
Product ID		CE-0063CQ3356		

Note

The supply values are only for reference (e.g. in the gas contract application) or for a supplementary, rough estimate to check the volumetric settings. Due to factory settings, the gas pressure must not be altered from these values. Reference: 15 °C, 1013 mbar (101.3 kPa).

^{*1} Only when operating with LPG P

Final decommissioning and disposal

Viessmann products can be recycled. Components and substances from the system are not part of ordinary household waste.

For decommissioning the system, isolate the system from the power supply and allow components to cool down where appropriate.

All components must be disposed of correctly.

DE: We recommend using the disposal system organised by Viessmann. Operating fluids (e.g. heat transfer medium) can be disposed of at municipal collection points. Viessmann sales offices can provide further information.

Declaration of conformity

Declaration of Conformity for the Vitodens 100-W

We, Viessmann Werke GmbH & Co. KG, D-35107 Allendorf, confirm as sole responsible body that the product **Vitodens 100-W** complies with the following standards:

EN 15036-1

EN 60 335-1

EN 15502-1

EN 60 335-2-102

EN 15502-2-1

EN 61 000-3-2

EN 55 014-1

EN 61 000-3-3

EN 55 014-2

In accordance with the following Directives, this product is designated with **CE**:

2004/108/EC

2010/30/EU

2006/95/EC

811/2013

2009/125/EC

813/2013

2009/142/EC

Allendorf, 01 October 2015

Viessmann Werke GmbH & Co KG



Authorised signatory Manfred Sommer

Keyword index

B

Boiler water temperature sensor	51
Burner gasket.....	37
Burner gauze assembly.....	37
Burner installation.....	40
Burner removal.....	37

C

CO ₂ content check.....	35
Combustion chamber cleaning.....	39
Commissioning.....	21
Condensate.....	13
Condensate drain.....	13, 40
Connection diagram.....	77
Connections.....	8, 11
Control unit, closing.....	19
Control unit, opening.....	15
Cylinder temperature sensor	52

D

Declaration of Conformity.....	82
Diaphragm expansion vessel.....	41
Dimensions.....	8

E

Electrical connections.....	16
-----------------------------	----

F

Fault.....	46
Fault code.....	46
Fault display.....	46
Filling function.....	21
Filling the system.....	21, 22
Fill water.....	21
Flow limiter.....	55
Flue gas cascade.....	32
Flue gas temperature sensor.....	54
Flue pipe.....	14
Front panel, mounting.....	42
Front panel, removal.....	11
Front panel, removing.....	15
Frost limit.....	76
Frost protection.....	76
Function sequence.....	46
Fuse.....	57

G

Gas connection.....	13
Gas supply pressure.....	24
Gas train	24
Gas type changing	
– LPG.....	45
Gas type conversion	
– At control unit.....	45
– LPG.....	23
Gas type selected.....	23

H

Heat exchanger cleaning.....	39
Heating curve.....	76
Heating output reduction.....	25

I

Ignition.....	38
Ignition electrode.....	38
Ionisation electrode.....	38

L

Limits	
– Flue gas values.....	23
LPG.....	23

M

Max. heating output.....	25
--------------------------	----

O

Outlet temperature sensor.....	53
Output adjustment	
– Multiple connection.....	26
Output matching	
– Flue gas cascade.....	32
– Flue pipe length.....	26
Outside temperature sensor.....	18, 50

P

Plate heat exchanger.....	56
Power supply.....	19
Pressure of the system.....	41
Product information.....	7
Pump rate adjustment.....	25

R

Report.....	78
Reset.....	48

S

Safety chain	53
Safety valve.....	13
Shared flue system connection.....	26
Static pressure.....	24
Supply pressure.....	24
System filling.....	21
System pressure.....	21, 22, 41

T

Temperature limiter.....	53
Trap.....	14, 40
Troubleshooting.....	49

V

Ventilation air pipe.....	14
Venting.....	22
Vitotrol 100	
– Connection.....	18

Keyword index (cont.)

W	
Wall mounting.....	9
Wall mounting bracket.....	9
Water quality.....	21
Water side connections.....	11
Weather-compensated mode.....	76

Applicability

Serial No.:			
7570671	7570672	7570673	7570674
7570675	7570676	7570677	
Viessmann Werke GmbH & Co. KG D-35107 Allendorf Telephone: +49 6452 70-0 Fax: +49 6452 70-2780 www.viessmann.com		Viessmann Limited Hortonwood 30, Telford Shropshire, TF1 7YP, GB Telephone: +44 1952 675000 Fax: +44 1952 675040 E-mail: info-uk@viessmann.com	

5697 787 GB Subject to technical modifications.