

Installation instructions for contractors

VIESMANN

Divicon

Heating circuit distributor

DIVICON



Safety instructions



Please follow these safety instructions closely to prevent accidents and material losses.

Safety instructions explained



Danger

This symbol warns against the risk of injury.



Please note

This symbol warns against the risk of material losses and environmental pollution.

Note

Details identified by the word "Note" contain additional information.

Target group

These instructions are exclusively intended for authorised contractors.

- Work on gas installations must only be carried out by a registered gas fitter.
- Work on electrical equipment must only be carried out by a qualified electrician.

Regulations to be observed

- National installation regulations
- Statutory regulations for the prevention of accidents
- Statutory regulations for environmental protection

- Codes of practice of the relevant trade associations
- All current safety regulations as defined by DIN, EN, DVGW, TRGI, TRF, VDE and all locally applicable standards
 - Ⓐ ÖNORM, EN, ÖVGW-TR Gas, ÖVGW-TRF and ÖVE
 - ⒸH SEV, SUVA, SVGW, SVTI, SWKI, VKF and EKAS guideline 1942: LPG, part 2

Working on the system


- Isolate the system from the power supply (e.g. by removing the separate fuse or by means of a mains isolator) and check that it is no longer 'live'.
- Safeguard the system against reconnection.
- Where gas is used as the fuel, close the main gas shut-off valve and safeguard it against unintentional reopening.

Index


Preparing for installation	4
Installation sequence	
Fitting to boiler with pipe assembly (accessories).....	5
Wall mounting.....	6
■ Fitting a single module (without manifold).....	6
■ Fitting several modules with manifold (accessories).....	8
Filling the system.....	15
Fitting the thermal insulation.....	16
■ Low loss header (if supplied).....	16
■ Manifold.....	17
■ Divicon with mixer.....	18
■ Divicon without mixer.....	20
Mixer extension kits	
Extension kit with mixer PCB.....	22
■ Overview of electrical connections.....	22
■ Connecting the extension kit to the control unit.....	23
■ Connecting two extension kits.....	27
■ Power supply.....	27
■ Connection and wiring diagram.....	30
■ Changing the rotational direction (if required).....	31
■ Specification.....	31
Extension kit without mixer PCB.....	33
■ Connecting the extension kit to the control unit.....	33
■ Changing the rotational direction (if required).....	33
■ Specification.....	34
Declaration of Conformity	36

Preparing for installation

Removing the thermal insulation



Fitting to boiler with pipe assembly (accessories)




(A) Heating flow


(B) Heating return

Wall mounting

Fitting a single module (without manifold)




Wall mounting (cont.)



Wall mounting (cont.)

Fitting several modules with manifold (accessories)




(A) Manifold for 2 Divicons

(B) Manifold for 3 Divicons


Wall mounting (cont.)

Manifold (H = 70 mm) for two Divicons



Wall mounting (cont.)

Manifold (H = 100 mm) for two Divicons




(A) Heating flow

(B) Heating return


Wall mounting (cont.)

Manifold (H = 70 mm) for three Divicons



Wall mounting (cont.)


Manifold (H = 100 mm) for three Divicons



(A) Heating flow


(B) Heating return

Wall mounting (cont.)



Wall mounting (cont.)


Low loss header (if supplied)



(A) Heating flow

(B) Heating return

Filling the system




1. For filling (with heating water), open the check valve in the heating return by positioning the slot of the screw in the vertical position.
2. For operation, position the slot of the screw in the horizontal position.

Note

Observe the marking on the adjusting screw.


Fitting the thermal insulation

Low loss header (if supplied)



Fitting the thermal insulation (cont.)

Manifold




Fitting the thermal insulation (cont.)

Divicon with mixer

Note


With several Divicons, first fit the thermal insulation on the right Divicon. For the remaining Divicons, fit the insulation from right to left.



(A) Cut if fitting a single module to the wall

(B) Cut out the thermal insulation if connecting with a union nut

Fitting the thermal insulation (cont.)




Fitting the thermal insulation (cont.)

Divicon without mixer

Note


With several Divicons, first fit the thermal insulation on the right Divicon. For the remaining Divicons, fit the insulation from right to left.



(A) Cut if fitting a single module to the wall

(B) Cut out the thermal insulation if connecting with a union nut

Fitting the thermal insulation (cont.)




Extension kit with mixer PCB

Note

Bundle the power cables below the extension kit and secure with cable ties.

Overview of electrical connections



F1 Fuse, 2A (slow)
S1 Rotary selector

230 V~ plugs

- 20 Heating circuit pump
- 40 Power supply 230 V/50 Hz
- 40A Power supply connection of accessories
- 52 Mixer motor

Low voltage connections

- 2 Flow temperature sensor
- 17 Return temperature sensor (in conjunction with the Vitotronic 300, type KW3, if installed)
- 145 KM BUS cable

Extension kit with mixer PCB (cont.)



Please note

Electronic modules can be damaged by electrostatic charges. Before beginning work, touch earthed objects, such as heating or water pipes, to discharge static loads.

Note

Apply a strain relief to all on-site cables. Close any unnecessary knockouts with cable grommets (not cut open).

Connecting the extension kit to the control unit


Connecting the Vitotronic 300, type KW3



Danger

Incorrect core assignment can result in serious injury and damage to the appliance. Take care not to interchange wires "L1" and "N".

- 145 KM-BUS to the control unit or to the KM-BUS distributor (accessories)
- 156 Power supply via control unit or via power distributor (accessories)



- (A) Extension kit
 - (B) To the control unit
- S1 For rotary selector position, see the following table

Extension kit with mixer PCB (cont.)

Set rotary selector:

Heating circuit affected by the mixer	Sensors connected	Rotary selector S1
Heating circuit with mixer M2	Flow temperature sensor	"2" (delivered condition)
	Flow temperature sensor and return temperature sensor	"3"
Heating circuit with mixer M3	Flow temperature sensor	"4"
	Flow temperature sensor and return temperature sensor	"5"


Wall mounted and storage combi boilers



Danger

Incorrect core assignment can result in serious injury and damage to the appliance.
Take care not to interchange wires "L1" and "N".

Extension kit with mixer PCB (cont.)



- (A) Extension kit
 40 Power supply
 145 KM-BUS
 S1 For rotary selector position, see the following table
- (B) Control unit
 "X3" KM-BUS at terminals "7" and "6" (disconnect plug 145)
 or
 with plug 145 to the KM-BUS distributor (accessories)
 96 Power supply


Note

If the mains power supply has already been allocated, see chapter "Power supply".

Set rotary selector:

Heating circuit which should be influenced by the mixer	Rotary selector S1
Heating circuit with mixer M2	"2" (delivered condition)
Heating circuit with mixer M3	"4"

Extension kit with mixer PCB (cont.)



- (A) Extension kit
 40 Power supply
 145 KM-BUS
 S1 For rotary selector position, see the following table
- (B) Control unit
 "X14" KM-BUS at terminals "1" and "2" (disconnect plug 145)
 or
 with plug 145 to the KM-BUS distributor (accessories)
 96 Power supply

Note


If the mains power supply has already been allocated, see chapter "Power supply".

Extension kit with mixer PCB (cont.)

Set rotary selector:

Heating circuit which should be influenced by the mixer	Rotary selector S1
Heating circuit with mixer M2	"2" (delivered condition)
Heating circuit with mixer M3	"4"

Connecting two extension kits



- (A) Extension kit for a heating circuit with mixer M2
- (B) Extension kit for heating circuit with mixer M3
- (C) KM BUS cable (standard delivery) to the control unit
- (D) KM BUS cable, 0.8 m long (cable kit accessory, part no. 7424 960)
- (E) Power supply (connect the power cable supplied, see the following chapter)
- (F) Power cable with plug $\boxed{40}$ and $\boxed{40}A$ (cable kit accessory, part no. 7424 960)

Power supply

Connect accessories with a total wattage **above 400 W directly** to the mains power supply.



Danger

Incorrectly executed electrical installations can result in injuries from electrical current and damage to the appliance.

Connect the power supply and implement all safety measures (e.g. RCD circuit) in accordance with the following regulations:

- IEC 60364-4-41
- VDE regulations



Extension kit with mixer PCB (cont.)



- Connection requirements specified by the local power supply utility
- Protect the power cable with a fuse/MCB of up to 16 A.




Danger

The absence of component earthing for the system can lead to serious injury from electric current if an electrical fault occurs.

The appliance and pipework must be connected to the equipotential bonding of the building.

- The mains isolator (if installed) must simultaneously isolate all non-earthed conductors from the mains with a minimum contact separation of 3 mm.
- If **no** mains isolator is installed, all non-earthed conductors must be isolated from the power supply by the upstream circuit breaker with a minimum contact separation of 3 mm.
- In addition, we recommend installing an AC/DC-sensitive RCD (RCD class B  ) for DC (fault) currents that can occur with energy efficient equipment.

Extension kit with mixer PCB (cont.)



- (A) Extension kit power supply
- (B) Control unit power supply
- (C) Power supply 230 V/50 Hz
- (D) Fuse (max. 16 A)
- (E) Mains isolator, 2-pole, on site (if installed)
- (F) Terminal box (on site)

Make the power supply connection in accordance with the diagram.



Danger

Incorrect core assignment can result in serious injury and damage to the appliance. Never interchange cores "L" and "N".



Please note

Incorrect phase sequence can cause damage to the appliance. Ensure phase equality with the control unit power supply.

Colour coding to IEC 60757


BN Brown

BU Blue

GN/YE Green/yellow

Extension kit with mixer PCB (cont.)

Connection and wiring diagram



A1 Main PCB

F1 Fuse

S1 Rotary selector

Plug 230 V~


- 20 Heating circuit pump
- 40 Power supply 230 V/50 Hz
- 40A Power supply connection of accessories
- 52 Mixer motor

Extension kit with mixer PCB (cont.)


Low voltage plugs

- 2 Flow temperature sensor
- 17 Return temperature sensor (in conjunction with the Vitotronic 300, type KW3, if installed)
- 145 KM BUS cable for connection with the control unit and an additional extension kit

Changing the rotational direction (if required)

1.  **Danger**
An electric shock can be life threatening.
Before opening the boiler, disconnect it from the mains voltage, e.g. at the fuse or mains isolator.

Remove the casing cover (see chapter "Overview of electrical connections").



Switch cores BK ▲ and BK ▼ on plug 52.

3. Refit the casing cover.
4. Check the rotational direction.


Specification

Flow temperature sensor

Sensor type	Viessmann cylinder temperature sensor (NTC)
IP rating	IP 53 to EN 60 529; ensure through design/installation
Permissible ambient temperature	
■ During operation	-20 to +90 °C
■ During storage and transport	-20 to +70 °C

Extension kit with mixer PCB (cont.)

Curve



Mixer motor

Rated voltage	230 V~
Rated frequency	50 Hz
Rated current	2 A
Power consumption	5.5 W
Protection class	I
IP rating	IP 32 D to EN 60 529, ensure through design/installation
Permissible ambient temperature	
■ During operation	0 to +40 °C
■ During storage and transport	-20 to +65 °C
Rated relay output breaking capacity	
■ Heating circuit pump	2 (1) A 230 V~
■ Mixer motor	0.2 (0.1) A 230 V~

Extension kit without mixer PCB


Note

Bundle the power cables below the extension kit and secure with cable ties.

Connecting the extension kit to the control unit


Connecting the flow temperature sensor

Push sensor plug [2] into the corresponding socket of the control unit.


 Installation and service instructions of the relevant control unit

Connecting the mixer motor

Push cable plug [52] into the corresponding socket of the control unit.

 Installation and service instructions of the relevant control unit

Changing the rotational direction (if required)



1. Switch OFF the power supply to the control unit.
2. Remove the enclosure lid.
3. Pull out 3-pin plug (A) in the mixer motor.
4. Insert 3-pin plug (A) in the mixer motor rotated through 180°.
5. Check the rotational direction.

Extension kit without mixer PCB (cont.)

Specification

Flow temperature sensor

Sensor type

Viessmann Ni500

IP rating

IP 32 to EN 60 529; ensure through design/installation


Permissible ambient temperature

- during operation
- during storage and transport

0 to +120 °C

-20 to +70 °C

Curve



Extension kit without mixer PCB (cont.)

Mixer motor

Rated voltage	230 V~
Rated frequency	50 Hz
Rated current	2 A
Power consumption	4 W
Protection class	I
IP rating	IP 42 to EN 60 529; ensure through design/installation
Permissible ambient temperature	
■ during operation	0 to +40 °C
■ during storage and transport	-20 to +65 °C
Rated capacity of the relay outputs	
■ Heating circuit pump	4 (2) A 230 V~
■ Mixer motor	0.2 (0.1) A 230 V~

Declaration of Conformity

Mixer extension kit

We, Viessmann Werke GmbH & Co. KG, D-35107 Allendorf, declare as sole responsible body that the named product complies with the provisions of the following directives and regulations:

2014/30/EU EMC Directive
2014/35/EU Low Voltage Directive
2006/42/EEC Machinery Directive

Applied standards

EN 55014-1: 2006 + A1:2009 + A2:2011
EN 55014-2: 2015
EN 60335-1: 2012 / AC:2014
EN 60335-2-102: 2006 + A1:2010

In accordance with the listed directives, this product is designated with **CE**.

Allendorf, 31/08/2016

Viessmann Werke GmbH & Co. KG



Authorised signatory Manfred Sommer

Viessmann Werke GmbH & Co. KG
D-35107 Allendorf
Telephone: +49 6452 70-0
Fax: +49 6452 70-2780
www.viessmann.com

Viessmann Limited
Hortonwood 30, Telford
Shropshire, TF1 7YP, GB
Telephone: +44 1952 675000
Fax: +44 1952 675040
E-mail: info-uk@viessmann.com

5443 825 GB Subject to technical modifications.